



RUBBER GUYS
T937 **.69**
T932 **.79**



CANOPY LOOPS
T352 75mm **.80p**
T354 100mm **.86p**
T363 150mm **.99p**



EYELET KITS
T020 6.75mm **10.90**
T022 7.94mm **10.90**
T024 9.53mm **12.20**
T026 11.11mm **14.90**
T028 12.7 mm **18.84**



BRASS EYELETS & WASHER KIT
T668430 6.7mm
T668431 8.0mm
T668432 9.5mm
T668433 11.1mm
T668434 12.7mm



PLASTIC FABRIC EYELETS
P150 WHITE **3.95**
P152 BLUE **3.95**



LIFT DOT STUD WOOD FIXING
T035 PP **2.86**



LIFT DOT STUD EX LONG PK 2
T034X **6.00**



LIFT DOT STUD NUT & BOLT
T040 PK 2 **2.86**



LIFT DOT STUD PLATE FIXING
T034 PK 2 **4.90**



LIFT DOT STUD EX HIGH PK2
T034X **£6.00**

LIFT DOT EYE MATERIAL PK 2
T036 **2.86**



TURN BUTTON MATERIAL PK 2
T052 **2.86**



TURN BUTTON WOOD PK 2
T054 **2.86**



EX HIGH TURN BUTTON TO WOOD PK 2
T 055 **4.90**



LIFT DOT CLOTH STUD PK 2
T032 **2.86**



TURN BUTTON EYE CLOTH
T056 **2.86**



S/S LACING HOOKS X 4
R668441**6.42**



PRESS STUDS CLOTH TO CLOTH
T100 **29.99**



PRESS STUDS CLOTH TO WOOD/METAL
T101 **29.99**



PRESS STUD KIT S/STEEL PK 10 FABRIC TO WOOD
M668420



PRESS STUD KIT S/STEEL PK 10 FABRIC TO FABRIC
M668421

W4 PRESS STUDS NICKEL PLATED
T37 **6.62**



TURNBUTTON FASTNER FABRIC TO FABRIC KIT NICKEL PLATED X 5
M668402 **8.92**



TURNBUTTON FASTNER FABRIC TO METAL KIT NICKEL PLATED X 5
M668400 6MM **8.52**
M668403 8MM **8.62**
M668404 10MM **14.64**



LIFT THE DOT FASTNER KIT FABRIC TO FABRIC NICKEL PLATED X 5
M668410 **9.22**



LIFT THE DOT FASTNER KIT FABRIC TO METAL NICKEL PLATED X 5
M668411 STD **12.36**
M668412 DOUBLE **19.62**



LIFT THE DOT FASTNER KIT WITH M5 STUD NICKLE
M668413 STD **12.12**
M668414 DBL HIGHT **14.28**



LIFT THE DOT FASTNER KIT WITH WOOD SCREWS
M668415 STD **10.24**
M668416 HIGH **13.24**



STARBRITE SNAP KIT
M088601 **31.04**