


RUBBER GUYS

M932 EACH 1.66
M933 x 4 75mm 6.65
M934 x 2 150mm 6.65



M008 S/S HOOKS x 2 3.25

CANOPY LOOPS

M352 75mm 1.40
M354 100mm 1.60
M355 150mm 1.70
BLACK
M353 100mm 1.60
M356 150mm 1.70

HIPKISS EYELET KITS

M020 6.75mm 11.95
M022 7.94mm 11.95
M024 9.53mm 13.45
M026 11.11mm 16.35

BRASS EYELETS & WASHER KIT AF

M668430 6.7mm 11.63
M668431 8.0mm 11.63
M668432 9.5mm 13.67
M668433 17.63
M668434 12.7mm 19.46

BRASS EYELETS

M020R 6.75mm 4.40
M022R 8.0 mm 4.40
M024R 9.5 mm 4.40
M026R 11.1mm 6.65



LIFT DOT STUD WOOD FIXING M035 PP 3.25



LIFT DOT STUD EX LONG PK 2 M034X 8.25



LIFT DOT STUD NUT & BOLT M040 PK 2 3.25



LIFT DOT STUD PLATE FIXING M034 PK 2 5.45



LIFT DOT STUD EX HIGH PK2 M034X £6.00



LIFT DOT EYE MATERIAL PK 2 M036 3.25



TURN BUTTON MATERIAL PK 2 M052 3.25



TURN BUTTON WOOD PK 2 M054 3.25



EX HIGH TURN BUTTON TO WOOD PK 2 M 055 5.45



TURN BUTTON WOOD FIXING M053 3.25



LIFT DOT CLOTH STUD PK 2 M032 3.25



TURN BUTTON EYE CLOTH M056 3.25



PRESS STUDS CLOTH TO CLOTH M100 KIT 29.99
M100R SPARE 6.65



PRESS STUDS CLOTH TO WOOD/METAL M101 KIT 29.99
M101R SPARE 6.65



PRESS STUD KIT S/STEEL PK 10 FABRIC TO WOOD M668420 11.56



PRESS STUD KIT S/STEEL PK 10 FABRIC TO FABRIC M668421 11.56



W4 PRESS STUDS NICKEL PLATED M37652 1/2" 4.72
M37659 3/8 3.99



TURNBUTTON FASTNER FABRIC TO FABRIC KIT NICKEL PLATED X 5 M668402 9.83



TURNBUTTON FASTNER FABRIC TO METAL KIT NICKEL PLATED X 5 M668400 6MM 11.18
M668403 8MM 9.62
M668404 10MM 16.52



FABRIC TO FABRIC NICKEL PLATED X 5 M668410 10.28



FABRIC TO METAL NICKEL PLATED X 5 M668411 STD 13.91
M668412 DOUBLE 19.62

TURN BUTTON KIT M668401_6mm 8.52



LIFT THE DOT FASTNER KIT WITH M5 STUD NICKLE M668413 STD 13.04
M668414 DBL HIGHT 15.96



LIFT THE DOT FASTNER KIT WITH WOOD SCREWS M668415 STD 10.84
M668416 HIGH 14.39



STARBRITE SNAP KIT M088601 32.50



PLASTIC FABRIC EYELETS M150 WHITE 4.40
M152 BLUE 4.40



EYELET PUNCH M37678 3.50