



BLADE FUSES


- E37534 3AMP 1.35
- E930 5AMP 1.35
- E931 7.5AMP 1.35
- E932 10 AMP 1.35
- E933 15 AMP 1.35
- E933a 20 AMP 1.35
- E934 25 AMP 1.80
- E9344 30 AMP 1.80



- BLADE FUSE
4 WAY HOLDER**
E137594 4.32
w4



- MAXI FUSE 4.98**
E890563 30amp
E890564 40amp
E890565 50amp
E890566 60amp




- MAXI FUSE
BLOCK SYSTEM**
fuse rating 30-80 amps
E825006 35.05



- BLADE FUSE BOX**
E802300 4 FUSES 6.23
E802301 6 FUSES 7.46
E802302 8 FUSES 8.76



- BLADE FUSE HOLDER**
E934A x2 4.40
E137542 1.85



- SCREW TERMINAL BLADE FUSES BLOCKS**
E825025 6 circuit with negative 56.35
E825026 12 " " " 70.54



- CONTINENTAL FUSE HOLDER**
E935 2 WAY 6.65 E937 6 WAY 11.00
E936 4 WAY 9.30 E938 8 WAY 14.95



- BLADE FUSE HOLDER**
E82110 20 amp 3.16
E80211 30amp 3.52




- INLINE GLASS FUSE HOLDER**
E897 20AMP BLUE 2.00
E802100 8AMP RED 1.20
E802101 17AMP GREEN 1.35



- STERLING FUSE BLOCK**
E3448 AUE & AUE/L 15.22



- SINGLE FUSE BLOCK**
E 1428 15.22



- AUE/L FUSE**
E0020L 2.96

- AUE FUSE**



- SCREW
FUSE HOLDER**
E825021 6.75
E1020252 29mm 1.25
E1020253 20mm 1.25



- REPLACEMENT FUSE
HOLDER RED CAP**
E20018 VERT 1.75
E20019 HOR 1.75



- FUSE HOLDER
RED SNAP IN**
E899 10AMP 5.45
E898 16AMP 4.40



- FUSE HOLDER
RED CAP**
E200181 V 1.19
E200191 H 1.19



- SLOW BLOW FUSE**
E0020L 3.58



- 20MM GLASS FUSES x 3**
E924 1 AMP 1.80
E925 2 AMP 1.80
E926 3AMP 1.80
E927 5 AMP 1.80
E928 8 AMP 1.80
E929 10 AMP 1.80



- 30MM GLASS FUSES x3**
E910 3 AMP 1.35
E911 5AMP 1.35
E912 10AMP 1.35
E913 15 AMP 1.35
E914 25 AMP 1.35
E915 35AMP 1.35



- CONTINENTAL FUSE x3**
E906 8 white 1.80
E902 red 1.80
E908 blue 1.80
E905 yellow 1.80
E37033 MIX W4 1.45



- GLASS RADIO FUSES PK x3**
E917 1 AMP 1.35
E919 3AMP 1.35
E920 5 AMP 1.35
E921 7 AMP 1.35
E922 10 AMP 1.35