

BLADE FUSES

E37534	3AMP	1.35
E930	5AMP	1.36
E931	7.5AMP	1.36
E932	10 AMP	1.36
E933	15 AMP	1.36
E933A	20 AMP	1.36
E934	25 AMP	1.80
E9344	30 AMP	1.80

**BLADE FUSE
4 WAY HOLDER**

E137594 **4.32**
W4

MAXI FUSE 5.28

E890563	30AMP
E890564	40AMP
E890565	50AMP
E890566	60AMP

**MAXI FUSE
BLOCK SYSTEM**

E825006 **35.05**

BLADE FUSE BOX


E802300	4 FUSES	6.31
E802301	6 FUSES	7.46
E802302	8 FUSES	8.76



BLADE FUSE HOLDER

E934A X2 **4.40**

E137542 **1.85**



SCREW TERMINAL BLADE FUSES BLOCKS

E825025 6 CIRCUIT WITH NEGATIVE **56.26**

E825026 12 " " " **71.14**

E825028 **49.72**

6 CIRCUIT

CONTINENTAL FUSE HOLDER

E935 2 WAY **6.65** E937 6 WAY **11.95**

E936 4 WAY **9.30** E938 8 WAY **14.95**



BLADE FUSE HOLDER

E82110 20 AMP **3.16**

E80211 30AMP **3.52**




INLINE GLASS FUSE HOLDER

E897 20AMP BLUE **2.30**


E802100 8AMP RED **1.25**

E802101 17AMP GREEN **8.42**



STERLING FUSE BLOCK

E3448 AUE & AUE/L **15.22**



SINGLE FUSE BLOCK

E1428 **15.22**



AUE/L FUSE

E0020L **2.96**

AUE FUSE



**SCREW
FUSE HOLDER**

E825021 **6.75**

E1020252 29MM **1.25**

E1020253 20MM **1.25**



**REPLACEMENT FUSE
HOLDER RED CAP**

E20018 VERT **2.29**

E20019 HOR **1.75**



**FUSE HOLDER
RED SNAP IN**

E899 10AMP **5.45**

E898 16AMP **4.40**



**FUSE HOLDER
RED CAP**

E200181 V **1.19**

E200191 H **1.19**



SLOW BLOW FUSE

E0020L **3.58**



20MM GLASS FUSES X 3

E924	1 AMP	1.80
E925	2 AMP	1.80
E926	3 AMP	1.80
E927	5 AMP	1.80
E928	8 AMP	2.30
E929	10 AMP	1.80



30MM GLASS FUSES X3

E910	3 AMP	1.36
E911	5 AMP	1.36
E912	10 AMP	1.36
E913	15 AMP	1.36
E914	25 AMP	1.36
E915	35 AMP	1.36



CONTINENTAL FUSE X3

E906	8 WHITE	1.80
E902	RED	1.80
E908	BLUE	1.80
E905	YELLOW	1.80
E37033	MIX W4	1.45



GLASS RADIO FUSES PK X3

E917	1 AMP	1.36
E919	3 AMP	1.36
E920	5 AMP	1.36
E921	7 AMP	1.36
E922	10 AMP	1.36